


# **Silky ZÜBAT** POLE SAW

## EXPLODED VIEW



Ref. No.	Part No.	Part Name	
1	271-33	Blade 330mm, Zubat	
2,4,5,6	270-00-41	Scabbard set	
*	3	272-00-31	Male clip scabbard
7	272-00-51	Blade fixing pipe	
8	102-04-46	Screw (black, metal)	
9	102-04-47	Nut (black, metal)	
10	121-04-33	Washer	
11	177-04-36	Washer M6	
12	177-04-37	Spring washer M6	
13	365-04-39	Bolt	
14	370-04-76	Stopper button spring	
15	365-04-38	Stopper button	
16	370-04-77	Spring fixing bolt	
*	17	234-04-05	Shacking-proof, cover
*	18	234-04-06	Shacking-proof, spacer
*	19	177-04-69	Shacking-proof, lever
*	20	177-04-78	Shacking-proof, rod pin
*	21	272-04-02	Rubber sleeve
*	22	272-04-03	Rubber sole
*	23	272-04-04	Rubber grip tape
24	272-00-22	Pole (S) 2700, Zubat 1200	
	272-00-25	Pole (S) 3300, Zubat 1500	
	272-00-28	Pole (S) 3900, Zubat 1800	
25	272-00-23	Pole (L) 2700, Zubat 1200	
	272-00-26	Pole (L) 3300, Zubat 1500	
	272-00-29	Pole (L) 3900, Zubat 1800	
8,9,10	272-01	Screw set (black, metal)	
11,12,13	365-03	Bolt set D	
*	17,18,19,20	234-00-51	Shaking proof stopper set

\*Call for availability: 1800-525-8872

2010. 01. 19