


# **Silky ZÜBAT** POLE SAW

## EXPLODED VIEW



Ref. No.	Part No.	Part Name
1	271-33	Blade 330mm, Zubat
2,4,5,6	270-00-41	Scabbard set
3	272-00-31	Male clip scabbard
7	272-00-51	Blade fixing pipe
8	102-04-46	Screw (black, metal)
9	102-04-47	Nut (black, metal)
10	121-04-33	Washer
11	177-04-36	Washer M6
12	177-04-37	Spring washer M6
13	365-04-39	Bolt
14	370-04-76	Stopper button spring
15	365-04-38	Stopper button
16	370-04-77	Spring fixing bolt
17	234-04-05	Shacking-proof, cover
18	234-04-06	Shacking-proof, spacer
19	177-04-69	Shacking-proof, lever
20	177-04-78	Shacking-proof, rod pin
21	272-04-02	Rubber sleeve
22	272-04-03	Rubber sole
23	272-04-04	Rubber grip tape
24	272-00-22	Pole (S) 2700, Zubat 1200
	272-00-25	Pole (S) 3300, Zubat 1500
	272-00-28	Pole (S) 3900, Zubat 1800
25	272-00-23	Pole (L) 2700, Zubat 1200
	272-00-26	Pole (L) 3300, Zubat 1500
	272-00-29	Pole (L) 3900, Zubat 1800
8,9,10	272-01	Screw set (black, metal)
11,12,13	365-03	Bolt set D
17,18,19,20	234-00-51	Shaking proof stopper set